



ACCUMEN®
SHAPES

Accumen Shapes Ltd
PO Box 22675, Otahuhu 1640
Unit D, 95 Hugo Johnston Drive
Penrose, Auckland 1061

p 09 270 9228

info@accumen.co.nz

www.accumen.co.nz

gst 103 389 747

DECORATIVE DETAILS

PRE-INSTALL CHECK LIST

1. Is the construction site clean and dry and is there a sheltered area for the decorative details to be stored?
2. As soon as the order arrives, unwrap and check to confirm lengths and sizes match what was ordered, and there is no damage caused by freighting.
3. Is the scaffolding supplied for your use safe and acceptable, and covers the area required?
4. On site, measure out the lineal metres required including extras allowed for any mitres or site wastage to confirm what was ordered tallies up with what is required. There may be extras needed that you weren't aware of that may require a VO (Variation Order) from your client. This means any extras can get to you sooner rather than later to reduce any holdups.
5. Check the surface area where the decorative details are to go is ready and weather tight.
6. You will need the following for the install of decorative details:
 - a. Mechanical fixings (eg. s/s nails, screws, concrete fixings etc.)
 - b. Washers to suit mechanical fixings (if required).
 - c. Adhesive plaster (20kg of adhesive plaster will spread approximately 3 square metres with a notched trowel).

Architects, designers and competent tradespersons must follow professional trade specifications for the application of a weathertight membrane on the building BEFORE fixing Accumen® decorative details. We strongly recommend that only informed competent installers fix the decorative details. Decorative details may be water repellent in themselves, but due to the diverse situations they may be used in, Accumen Shapes Ltd's warranty is therefore limited to the quality of the goods supplied.

adding **VALUE** to buildings

LIGHTWEIGHT • ROBUST • EXCEPTIONAL

- d. MS silicone for silicone bead or control joints (one 600mm grey sausage will provide approximately 16 lineal metre bead).
- e. Backing rod for any control joints.
- f. Mesh for joints.
- g. Spray foam type material (eg. Gorilla Nail Power or similar) that can be used to fill any gaps that may occur while installing the decorative details.
- h. Electric cut off mitre saw, or for larger decorative details, handsaws.
- i. Mitre box (if installing larger moulding).
- j. Sandpaper (36 grit? for standard DecraShape® mouldings).
- k. Masking Tape.
- l. Notched trowel (for applying the adhesive plaster).
- m. Trowel for any finishing work.
- n. Rubbish bin or large bags for any off cuts, and general rubbish that may occur while installing the decorative mouldings.
- o. Chalk line.
- p. Sponge (for blending out any surface plaster on the decorative details while installing).
- q. Access to clean water tap with hose fitting.
- r. Clean buckets.
- s. Sanding block.
- t. Plastic gloves.

ATTENTION TO DETAIL IS EVERYTHING
😊 ENJOY THE INSTALL 😊

Architects, designers and competent tradespersons must follow professional trade specifications for the application of a weathertight membrane on the building BEFORE fixing Accumen® decorative details. We strongly recommend that only informed competent installers fix the decorative details. Decorative details may be water repellent in themselves, but due to the diverse situations they may be used in, Accumen Shapes Ltd's warranty is therefore limited to the quality of the goods supplied.

adding **VALUE** to buildings

LIGHTWEIGHT • ROBUST • EXCEPTIONAL